

Heyco® Lockit™ Strain Relief Pre-Assembly Equipment Directory



TO ASSEMBLE Lockit™ Strain Relief Series	Catalog Page Ref.	Hand Pliers	USE THE FOLLOWING PART NOS.				C† Eurolock
			A Headlock	B Footlock	C Autolock		

RDD Lockits

RDD 100, RDD 100A RDD 101, RDD 101A	4-11 4-7	0026	ST16	ST14, ST14E†	ST13	ST13E
RDD 100-90, RDD 100A-90 RDD 101-90, RDD 101A-90 RDD 100-7, RDD 100A-7 RDD 101-7	4-14 4-13 4-12 4-12	0026	*	*	*	*
RDD 200, RDD 200-2 RDD 201, RDD 201-2 RDD 301, RDD 301-2 RDD 401, RDD 401-2	4-11 4-8 4-8 4-8	0027	ST17	ST19	ST18	*
RDD 200-90 RDD 201-90 RDD 301-90	4-14 4-13 4-13	0027	ST17-90	ST19-90	*	*
RDD 501 RDD 510	4-9 4-11	**	ST20	ST27	ST26	*
RDD 601	4-9	**	ST31	ST34	*	*
RDD 6N-2	4-7	**	ST32	ST33	*	*
RDD 701	4-9	**	ST35	*	*	*

ST Lockits

ST 100L	4-6	0023	ST12	ST11	ST10	*
ST 100N ST 101N	4-6 4-5	0020	OST1	OST4	OST3	OST3E
ST 101A	4-31	0025	ST15	OST0	OST6	*
ST 200N ST 201N, ST 301N	4-6 4-5	0073	OST7	OST9	OST8	*

† ST14E guarding meets European standards.
Eurolock **ST13E** and **OST3E** have a 230V 50/60 Hz rated motor.
* Consult Heyco for availability.
** Headlock, Footlock or Autolock required due to cable thickness.

To use Hand Pliers with Lockit™ Strain Reliefs:

Position on Wire

Squeeze Pliers

Push into Double D (RDD) or Rectangular (ST) Mounting Hole

or Set Aside for Future Final Assembly

