

WORK INSTRUCT	IONS	
	<u>→</u> 29.25 " +0.25"/-0" >	
CABLE		
	†	
	STEP 1: CUT CABLE (M0530-2408) AS SINGLE TO 29.25".	
	STEP 2: STRIP THE CABLE JACKET 1" MANUALLY USING THE HAND STRIPPERS AND REMOVE JACKET AND FILLERS.	
	STEP 3: ARRANGE THE WIRES IN ORDER ACCORDING TO THE COLOR CODE. TRIM THE WIRES ENDS AT 90° TO APPROX 9/16" LONG	_
	RJ45 CONNECTOR (S0405-0037)	_
	STEP 4: INSERT WIRES INTO RJ45 CONNECTOR (S0405-0037) PER COLOR CODE AND CRIMP USING THE AMP MODULAR CRIMPER WITH	I BLACK DOT DIE. –
	STEP 5: TEST FOR CONTINUITY AND PROPER COLOR CODE	00 ORIGINAL 8/24 LV SF REV DESCRIPTION DATE DR APR REVISION HISTORY
	STEP 6:LABEL TO CABLCON STANDARDS USING STANDARD LABELS (THT-75-427-3).	ALPHA CHARACTER IN REVISION BLOCK REPRESENTS CORRECTION TO DRAWING. AN IEWE COMPANY ALPHA CHARACTER IN REVISION BLOCK REPRESENTS CORRECTION TO DRAWING. THE INFORMATION CONTAINED IN THIS DRAWING IS THE SOLE PROPERTY OF CABLCON, INC. ANY REPRODUCTION IN PART OR WHOLE
		PROPERTY OF CABLCON, INC. ANY REPRODUCTION IN PART OR WHOLE WITHOUT THE WRITTEN PERMISSION OF CABLCON IS PROHIBITED. DATE DRAWN BY TITLE 8/6/24 LV T4640-0002-I29.25 SHT CODE 2 of 2 C RJ45 Patch Cord Flat Cable 29.25 inches