

SMA ADAPTERS



FIG. 29
RSA-3457



FIG. 30
RSA-3458



FIG. 31
RSA-3459



FIG. 32
RSA-3470



FIG. 33
RSA-3471



FIG. 34
RSA-3472



FIG. 35
RSA-3473



FIG. 36
RSA-3474



FIG. 37
RSA-3475



FIG. 38
RSA-3476, -1



FIG. 39
RSA-3477, -2



FIG. 40
RSA-3477-03



FIG. 41
RSA-3478



FIG. 42
RSA-3494

PHOTOS FOR REFERENCE ONLY, SHOWN AT 100% ACTUAL SIZE.

PART #	FIG	DESCRIPTION	NOTES	REPLACES OR EQUIVALENT TO	PLATING		
					BDY	P/C	DIE
RSA-3457	29	Adapter	SMA Male to UHF Female		N	G	T
RSA-3458	30	Adapter	SMA Male to BNC Female		N	G	T
RSA-3459	31	Adapter	SMA Male to BNC Male		N	G	T
RSA-3470	32	Adapter	SMA Female to Mini UHF Male		N	G	T
RSA-3471	33	Adapter	SMA Female to Mini UHF Female		N	G	T
RSA-3472	34	Adapter	SMA Female to TNC Male		N	G	T
RSA-3473	35	Adapter	SMA Female to TNC Female		N	G	T
RSA-3474	36	Adapter	SMA Female to UHF Male		N	G	T
RSA-3475	37	Adapter	SMA Female to UHF Female		N	G	T
RSA-3476	38	Adapter	SMA Female to BNC Male		N	G	T
RSA-3476-1	38	Adapter	SMA Female to BNC Male		G	G	T
RSA-3477	39	Adapter	SMA FEMALE TO N FEMALE		N	G	T
RSA-3477-03	40	Bulkhead Adapter	SMA Female to N Female Feed Through with Gasket & Double D-Flat		N	G	T
RSA-3477-2	39	Adapter	SMA Female to N Female		S	G	T
RSA-3478	41	Adapter	SMA Female to N Male		N	G	T
RSA-3494	42	Adapter	SMA Male to MHF Jack		G	G	T